



T

hch

CUTL FEED

PIECE 1A BOTTOM BASE PLATE 6mm






ADP 1000

3C

MIRROR IMAGE THIS PAGE

TO GET PIECE 10



AFT HATCH

CUT 25X 140 MM DEPRO  
ATTACH FORMERS

AFT HATCH MOLD FWD

10

AFT SHEETING

AS A GUIDE ONLY  
WILL VARY FROM  
to the other

12

BEVEL


1B WINGTOP LAYER 6n



AFT WATCH MOLD AFT FORMER

6mm

6mm


3D





INTAKE MOLD FORMER

31



TOP MIDDLE  
USE TEMPLATE  
ACTUAL SHAPE  
ONE AIRCRAFT

2E


F<sub>u</sub>  
↓

FORMER

N TO

M MOLD MIDDLE FORMER





6mm

3E